

Assembly Instructions for Bun Feet





Step 1. Unpack carton and inventory parts.

Step 2. Open drawers and locate box packed inside containing Bun Feet.

Step 3. Turn unit on its back in order to access bottom. Insert **DOWELS (4)** into non-threaded holes on the bottom of the unit and attach **BUN FEET** to the bottom of the unit use **BOLT (3)**, **SPRING WASHER (2)**, **FLAT WASHER (1)**, and tighten it with **SCREWDRIVER**. (Not Included)

Step 4. Turn unit upright carefully.

Note: During normal use everyday, bolts and nuts may loosen up. They should be periodically inspected and re-tightened to prevent damage to the furniture and (or) personal property or cause injury. Always check to be sure all hardware on this list is attached to the furniture properly and kept tightened at all times.

①		FLAT WASHER	5/16"	4PCS
②		SPRING WASHER	5/16"	4PCS
③		BOLT	5/16"	4PCS
④		DOWEL	40mm	8PCS

